





Dsp international b.v.
wholesale import

Judy - Running Assembly Instructions


- | | | | |
|-----|---|-------|---------|
| (A) |  | M6*30 | 34PCS+1 |
| (B) |  | | 2 PCS |
| (C) |  | M4*12 | 2 PCS |
| (D) |  | | 2 PCS |




1




2*2




3




4



5




6*3




7*2

1



2




4PCS

(A)



M6*30


8PCS




Dsp international b.v.
wholesale import

Judy - Running Assembly Instructions

3



4




A



M6*30

10PCS


7*2



Dsp international b.v.
wholesale import

Judy - Running Assembly Instructions

5



A  M6*30 16PCS

6

